

<b>Product</b>	LuxeWall® Luxury Wall Cladding
<b>Product Description</b>	LuxeWall® is a modern, lightweight residential wall cladding solution developed with a concealed fixing system to fasten to timber and metal stud wall framing. The system uses architectural steel faced insulated wall cladding conceal fixed in a vertical orientation. LuxeWall® is available in standard wall thicknesses of 50mm & 75mm (Note: 90 to 200mm wall thicknesses are available via special order).
<b>Supplier</b>	BONDOR®
<b>Contact Number</b>	1300 300 099
<b>Website</b>	www.bondor.com.au

## Product Overview

<b>Core</b>	EPS-FR with CorePlus®
<b>Width (cover mm)</b>	1200, 900^
<b>Thickness (mm)</b>	50, 75 (other thicknesses available on request)
<b>Length</b>	Up to 6.5m (check for availability)
<b>External Material</b>	BlueScope® COLORBOND® Steel 0.6mm G300
<b>External Finishes</b>	Plain, VJ^
<b>Exterior Colour Options</b>	Metallic Cosmic®, Metallic Astro®, Matt Basalt®, Matt Surfmist®
<b>Internal Material</b>	BlueScope® COLORBOND® Steel 0.6mm G300 with HygienePlus®
<b>Internal Finishes</b>	Plain
<b>Interior Colour Options</b>	Surfmist
<b>Paint System</b>	AS/NZS 2728 & AS 1397
<b>Accreditations</b>	Codemark Certificate Number CM40203
<b>Acoustic Properties</b>	Rw 35, 40 *depending on construction
<b>Material Group Numbers</b>	Group 1
<b>Bushfire Attack Level</b>	BAL-40 (All exposed core to be covered with flashing)

## Technical Properties

### Thermal - AS/NZS 4859.1

<b>Total R-Value (m<sup>2</sup>K/W)</b>	50, 75mm SL Grade LuxeWall® delivers Total R-value of 1.9, 2.5 for insulation average temperature of 15°C. Contact us for other temperatures and construction methods.
---	--

### Acoustics - AS 1191, AS/NZS 1276 & AS/NZS ISO 717.1

<b>R<sub>w</sub> Value (dB)</b>	LuxeWall® has been tested in accordance with the requirements of AS 1191. The Weighted Sound Reduction Index (R <sub>w</sub> ) of the panel is calculated using AS/NZS 1276 and AS/NZS ISO 717.1 respectively with acoustic values of R <sub>w</sub> 35 or 40 for EPS & 40 or 45 for MW. Refer to Bondor® Australia for your specific application.
---------------------------------	--

## Fire

<b>Fire Hazard Properties</b>	AS/NZS 1530.3
<b>Ignitability Index</b>	0
<b>Spread of Flame Index</b>	0
<b>Heat Evolved Index</b>	0
<b>Smoke Index</b>	2-3
<b>SMOGR<sub>RC</sub></b>	< 100
<b>Material Group Numbers AS 5637.1 / AS ISO 9705</b>	LuxeWall® EPS-FR & MW steel skinned insulated building panels conform to the requirements of the BCA as Group 1. Refer Bondor® for more information.
<b>Bushfire Attack Level AS 3959</b>	LuxeWall® is suitable for use as external walls of Class 1 to 10 buildings to be constructed in designated bushfire prone areas that have a BAL-40 or less.

## Structural - AS/NZS 1170, AS 1562.1, AS4040

<b>Span Tables</b>	Bondor® provides the latest Ultimate Limit State Span Tables developed specifically for Australasian conditions, in accordance with AS/NZS 1170, AS 1562.1 & AS 4040. Refer to Span Tables for detailed design guidelines and Span Tables for Non-Cyclonic Regions A & B. Refer to Span Table Notes for design guidelines relating to fixing, and deflection limits. The panel design shall be specified by the certifying engineer as determined from the Span Tables.
--------------------	---

<b>Support Details</b>	The support spacing shall be specified by the structural engineer as determined from the Span Tables.
------------------------	---

## Safe Handling & Installation

<b>Panel Length</b>	Up to 16m, however site, transport and wind load restrictions can limit panel length.
---------------------	---

<b>Storage</b>	Panels should always be kept dry and if placed on site, stored off the ground, slightly inclined, allowing adequate drainage and ventilation of the panel pack. No other materials to be stored / stacked on top of panel pack.
----------------	---

<b>Handling</b>	In the event of manual handling, careful consideration should be given to panel weight and appropriate PPE. Consider using mechanical aides if necessary.
-----------------	---

<b>Safety</b>	The contractor is to determine and use safe working methods throughout the installation and construction period, which complies with OHS requirements. A safe work method template (although NOT project specific) is available from Bondor®.
---------------	---

<b>Supporting Frame</b>	The builder is to ensure that the substrates including slabs and kerbs; and sub frames are straight, smooth and fit for purpose.
-------------------------	--

<b>Fixing</b>	Fixings are to meet the requirements of BlueScope TB-16 Fasteners for Roofing and Walling Product Selection Guide. Fasteners must be manufactured from high grade carbon steel with a minimum class 4 anti-corrosion coating as per Australian Standards. Refer to Span Tables Notes for design guide relating to screw fixing and IPCA for cold storage compliance.
---------------	--

<b>Flashing</b>	Flashings are manufactured from 0.55mm BlueScope COLORBOND® steel and installed to AS 1562.1 or as otherwise specified in the Bondor® Cold Storage or Cladding Construction Drawings. Aluminium can be used if there is no Group Number requirement.
-----------------	--

<b>Sealant</b>	Sealant to be neutral cure and meet recommendations for sealants as per BlueScope TB-9 Sealants for Exterior Finishes. Silicon, polyurethane, butyl mastic and acrylic based sealants may be appropriate if neutral cure and recommended by their manufacturer for use on COLORBOND® steel and for the application. Sealant to be placed between flashings/angles and panel and between panel joints as shown on the Bondor® Standard Construction Details.
----------------	---

<b>Installation</b>	<p>Installation as per the Bondor® Standard Construction Details.</p> <ul style="list-style-type: none"> <li>• Panels are to be cut &amp; trimmed to ensure a flush finish.</li> <li>• Panels are to be confirmed square &amp; plumb as per project requirements.</li> <li>• Panels are to be cut with a suitable metal cutting circular type saw. Angle grinder is not recommended.</li> <li>• Penetrations for outlets, vents, flues etc. are to be flashed &amp; sealed with appropriate materials. Refer flashing details above.</li> <li>• Gaps to be filled with a suitable sealant or foam filler.</li> <li>• Refer to Bondor® Standard Construction Details &amp; Fixing Details above for fastener requirements.</li> <li>• Remove all swarf and any foreign matter immediately from all panel surfaces as per BlueScope TB-5 Swarf staining of steel profiles.</li> </ul>
---------------------	---

<b>Maintenance</b>	Refer to BlueScope TB-4 Maintenance of COLORBOND® and Zinalume® Steel and the relevant Bondor® maintenance information.
--------------------	---

## Warranties & Disclaimers

<b>Warranty</b>	Bondor® offer a conditional warranty up to 15 years on LuxeWall® for use as architectural wall panels from install date for projects on an application basis, dependent on project location, design, installation, end use, environmental conditions and maintenance of the product. Please contact Bondor® sales team with your specific project details for more information on the available conditional warranties.
-----------------	---

<b>Disclaimers</b>	Under certain light conditions this product may show an undulating surface which can vary depending on exterior profile and steel gauge selection as well as the environments varying light conditions.
--------------------	---